CHAPTER I

SUEZ CANAL NAVIGATION FEATURES

SECTION I1

PILOTAGE

Art.11 - Pilotage (for Pilotage dues see Art. 103).

A. - General: All vessels entering or leaving Canal must take a pilot (Pilotage isCompulsory). However, the SCA reserves the right to assign a tug master on board vessels under 1 500 tons Gross, and under 800 tons Gross a coxswain, instead of a pilot.

Navy ships and vessels carrying dangerous cargo must have a pilot regardless of their tonnage.

Roads pilots on board vessels arriving from sea shall hand over to the Master, the Declaration of State of Navigability and the Pilotage Form to the Master.

Masters are held solely responsible for all damage or accidents of whatever kind resulting from the navigation or handling of their vessels directly or indirectly by day or night.

The pilot must inform the Movement Control Office or the Port Office immediately by W/T, R. TELEX, Inmarsat and/or V.H.F (See Part III Art. 86). if his advice regarding the safety of navigation is not accepted or not respected by the vessel (See Art. 105).

B. - Port Said:

(1)Southbound vessels:

- a) VLCC's ULCC's Containerships, LASH vessels over 35 000 SC.G.T., L.P.G. & L.N.G and vessels over 42 feet draught are piloted from Northern Anchorage Area for Canal transit through the East Approach Channel.
- b) Other vessels, either for local trade or for intending to transit the Canal, are piloted from Fairway Buoy to berths in the harbour through the West Channel.
- c) Vessels are piloted between Port Said Harbour and Port of Suez by Canal pilots who are relieved at Ismailia.

(2) Northbound vessels:

- a) Through east branch, vessels are piloted till Km. 3.000. However, on Master's request, Pilotage may extend till Hm.80.
- b) Through west branch vessels are piloted till Hm. 80 if weather permits. However, on Master's request, Pilotage may end at Hm. 22 on Master's responsibility.

C. - Port of Suez:

- (1) Northbound vessels:
 - a) VLCC's, ULCC's Containerships, L.P.G. & L.N.G. (Loaded or N.G.F.) and vessels over 38 feet draught are piloted from anchorage area south of Conry Rock for Canal transit.
 - b) Other vessels are piloted from waiting area till anchorage area in the Port of Suez.
 - c) Vessels are piloted from Port of Suez and Port Said Harbour by Canal pilots who are relieved at Ismailia.
 - (2)Southbound vessels:
 - a) Southbound convoy and vessels at Port of Suez Anchorages sailing south are piloted till Hm 80.50. However, on Master's request, piloting may end at Hm. 44.4 (New Port Rock).
 - b) Vessels have to maintain course through the channel till the last pair of buoys keeping the Separation Zone on the Port Side.

D. - Master and pilot:

- (1) Master: When a vessel is transiting the Canal, the Master or his qualified representative should be present at all times on the bridge, he has to keep the pilot informed of any individual peculiarities in the handling of the vessel so that the pilot might be in a position to give better advice to control the navigation and movement of the vessel.
- (2) Pilot: The duties of pilots commence and cease at the entrance buoys of Port Said and Port of Suez. He only gives advice on manoeuvring the vessel, course to steer, etc. He puts at the disposal of the Master his experience and practical knowledge of the Canal, but as he cannot know the defects or difficulties of manoeuvrability for every vessel, the responsibility falls completely upon the Master. The pilot has to ensure that the vessel abides by:
 - a) The articles of Rules of Navigation.
 - b) The orders of transit given by Suez Canal Port Office.

The manoeuvre and orders are carried out under the direction of the Master who is solely responsible for the ship. It is therefore for the Master, taking into account the indications given by the pilot, to give the necessary orders to the helm, to the engines and tugs. If, in the interest of quick manoeuvres the Master thinks it preferable to allow the pilot to give orders directly, manoeuvres carried out in these circumstance shall be considered as having been carried out by the order of the Master and engage his sole responsibility.

E. - Moving in Suez Canal Waters without Pilot's Assistance:

- (1) Unless explicitly Authorized by the Suez Canal Authority, the following must be considered:
 - a) Whenever a vessel moves in Canal Waters or Port Said Harbour without having a pilot on board, she shall be charged an additional due of (21 500 U.S. Dollars) (Vessels under 300 tons S.C.G.T. are subject to Rules of Navigation for Small Craft).
 - b) An additional due of (3200 U.S. Dollars) shall be charged to vessels moving in Port of Suez Anchorages, or entering or leaving at Port of Suez without having a pilot on board (Vessels under 300 tons S.C.G.T. are exempted as per law 161/59).
 - c) These dispositions do not apply in the event if the pilot being suddenly unable to carry on with his duties due to sickness or death. In this case the Master must:
 - 1 -Warn the vessels astern of his intended manoeuvre by means of the visual and sound signals as well as V.H.F, or R.TELEX and or Inmarsat Via SUQ.
 - 2 -Reduce speed and contact Suez Canal Port Office to get advice for making fast if in the Canal, or the entrance channels; or dropping anchor if at the Lakes.
 - 3-The Movement Office in Ismailia is to be informed at all times by V.H.F, and confirmed by R.TELEX and or Inmarsat via SUQ.

(2) Exceptions:

In case of bad weather to the extent of not allowing Pilotage in Canal approach channels, Masters will be authorized by notice from the Suez Canal Port Office, to sail with their vessels on their own responsibility at the following positions:

- a) For southbound convoy, from Km. 162 to sea.
- b) For northbound convoy, from Km. 3.000 east of Port Said channel northward to sea.
- c) For vessels leaving Port Said Harbour through west approach channel, from Hm.22 northward.

- d) For vessels anchoring in Port of Suez anchorages wishing to head to sea, also, for vessels in waiting area wishing to enter Port of Suez Anchorage Area.
- e) For vessels entering Port Said Harbour either for transiting the Canal or for trade, through west approach channel till Hm. 50 approx., where Roads pilot will board vessels.
- f) For Other vessels joining northbound convoy from Port of Suez anchorage Canal pilots will board vessels at Km. 161 approx.
- N.B.: For items c, d, f, the time of proceeding will be fixed by Suez Canal Port office.
 - 1- An extra pilot for assisting the pilots in charge may be assigned on Master's request or by the CA if Deemed necessary.
 - 2- A due of (300 U.S. Dollars) for every additional Canal Pilot and (150 U.S. Dollars) for every additional Roads pilot is charged.
 - 3- In all cases, advice will be given if necessary by shore radars to vessel's master.

F. - Calling Pilots Unnecessarily:

When a vessel signals for pilot, and if is found when boarding that she is not ready to get underway at the limit time, the vessel is liable to be delayed and pilot disembarked. The vessel will pay extra Pilotage dues for the new pilot as mentioned hereafter.

G. - Extra Pilots:

Extra pilots shall be assigned in the following cases:

- (1) Vessels over 80000 tons S.C.G.T.
- (2) Fourth generation containerships, Third generation containerships (over 60000 S.C.G.T) and Lashers of 35000 S.C.G.T. and over.
- (3) Vessels having cargoes or installations impeding visibility from inside the wheelhouse (Bad View).
- (4) If a pilot is disembarked and relieved by another pilot in case of slow speed vessels, vessels having trouble which prevents to continue transit with the same convoy, or vessels that have to transit by day light only.
- (5) If a vessel has no accommodation for the pilot to rest while anchoring in Bitter Lakes or making fast in mooring places for a long period.
- (6) On Master's request or by SCA if deemed necessary.
- (7) Vessels draught 53 feet and over .